



FEL-PRO INSTALLATION TIPS

Fel-Pro products are the result of exhaustive research and strict quality control. However, no sealing product is better than the quality of its installation.

WATER OUTLET, WATER PUMP, FUEL PUMP AND TIMING COVER GASKETS

If a supplementary sealer is desired, apply a thin coat of gasket sealer to both sides of gasket(s).

FLYWHEEL BOLTS

REINSTALL FLYWHEEL to crankshaft. Note: On some engines that use a one-piece rear main bearing seal, a condition may exist where the bolt holes in the crankshaft rear flange have been drilled too deep by the manufacturer. This can result in oil seepage which may be misdiagnosed as coming from the oil pan or rear main bearing seal. To prevent seepage, coat bolt threads with thread locking sealer. Torque securely to OEM specifications.

ROTATING SHAFT SEALS

RUBBER SEAL(S): Install seal with its **largest raised sealing lip toward the engine**. Two-piece rubber seals may be installed using a "shoehorn" installation aid placed underneath seals to protect them from sharp edges.

ROPE SEALS: Install seals into grooves of cap and block by firmly pressing packing into grooves with a "packing tool." Ensure that ends of seals protrude above face of cap and block.

-Continued-

IMPORTANT: Final interference of rope packing seals against crankshaft is critical. To achieve proper interference, it is best to install packings using correct **Packing Tool** for your engine. With "packing tool" in position, cut protruded ends of seals flush with cap and block.

LUBRICATE SEALING LIPS AND CRANKSHAFT with motor oil or grease. If engine will not be started within several days, grease is recommended.

IMPORTANT: Never install any seal without break-in lubricant protection.

REAR MAIN BEARING CAP: Prior to installation, apply anaerobic sealant to mating surfaces of cap or block. Avoid sealant on ends of seals.

OIL PAN GASKET

ATTACH AND ALIGN GASKET(S). Apply a quick-drying adhesive sparingly. Mount gasket and/or seals.

PRIOR TO INSTALLING OIL PAN apply a dab of RTV Black silicone sealer where all gaskets and seals meet.

© 2001 Federal-Mogul Corporation
Form No. I-637 (Rev. 6/01)

Printed in U.S.A.



FEL-PRO INSTALLATION TIPS

Fel-Pro products are the result of exhaustive research and strict quality control. However, no sealing product is better than the quality of its installation.

WATER OUTLET, WATER PUMP, FUEL PUMP AND TIMING COVER GASKETS

If a supplementary sealer is desired, apply a thin coat of gasket sealer to both sides of gasket(s).

FLYWHEEL BOLTS

REINSTALL FLYWHEEL to crankshaft. Note: On some engines that use a one-piece rear main bearing seal, a condition may exist where the bolt holes in the crankshaft rear flange have been drilled too deep by the manufacturer. This can result in oil seepage which may be misdiagnosed as coming from the oil pan or rear main bearing seal. To prevent seepage, coat bolt threads with thread locking sealer. Torque securely to OEM specifications.

ROTATING SHAFT SEALS

RUBBER SEAL(S): Install seal with its **largest raised sealing lip toward the engine**. Two-piece rubber seals may be installed using a "shoehorn" installation aid placed underneath seals to protect them from sharp edges.

ROPE SEALS: Install seals into grooves of cap and block by firmly pressing packing into grooves with a "packing tool." Ensure that ends of seals protrude above face of cap and block.

-Continued-

IMPORTANT: Final interference of rope packing seals against crankshaft is critical. To achieve proper interference, it is best to install packings using correct **Packing Tool** for your engine. With "packing tool" in position, cut protruded ends of seals flush with cap and block.

LUBRICATE SEALING LIPS AND CRANKSHAFT with motor oil or grease. If engine will not be started within several days, grease is recommended.

IMPORTANT: Never install any seal without break-in lubricant protection.

REAR MAIN BEARING CAP: Prior to installation, apply anaerobic sealant to mating surfaces of cap or block. Avoid sealant on ends of seals.

OIL PAN GASKET

ATTACH AND ALIGN GASKET(S). Apply a quick-drying adhesive sparingly. Mount gasket and/or seals.

PRIOR TO INSTALLING OIL PAN apply a dab of RTV Black silicone sealer where all gaskets and seals meet.

© 2001 Federal-Mogul Corporation
Form No. I-637 (Rev. 6/01)

Printed in U.S.A.



FEL-PRO INSTALLATION TIPS

Fel-Pro products are the result of exhaustive research and strict quality control. However, no sealing product is better than the quality of its installation.

WATER OUTLET, WATER PUMP, FUEL PUMP AND TIMING COVER GASKETS

If a supplementary sealer is desired, apply a thin coat of gasket sealer to both sides of gasket(s).

FLYWHEEL BOLTS

REINSTALL FLYWHEEL to crankshaft. Note: On some engines that use a one-piece rear main bearing seal, a condition may exist where the bolt holes in the crankshaft rear flange have been drilled too deep by the manufacturer. This can result in oil seepage which may be misdiagnosed as coming from the oil pan or rear main bearing seal. To prevent seepage, coat bolt threads with thread locking sealer. Torque securely to OEM specifications.

ROTATING SHAFT SEALS

RUBBER SEAL(S): Install seal with its **largest raised sealing lip toward the engine**. Two-piece rubber seals may be installed using a "shoehorn" installation aid placed underneath seals to protect them from sharp edges.

ROPE SEALS: Install seals into grooves of cap and block by firmly pressing packing into grooves with a "packing tool." Ensure that ends of seals protrude above face of cap and block.

-Continued-

IMPORTANT: Final interference of rope packing seals against crankshaft is critical. To achieve proper interference, it is best to install packings using correct **Packing Tool** for your engine. With "packing tool" in position, cut protruded ends of seals flush with cap and block.

LUBRICATE SEALING LIPS AND CRANKSHAFT with motor oil or grease. If engine will not be started within several days, grease is recommended.

IMPORTANT: Never install any seal without break-in lubricant protection.

REAR MAIN BEARING CAP: Prior to installation, apply anaerobic sealant to mating surfaces of cap or block. Avoid sealant on ends of seals.

OIL PAN GASKET

ATTACH AND ALIGN GASKET(S). Apply a quick-drying adhesive sparingly. Mount gasket and/or seals.

PRIOR TO INSTALLING OIL PAN apply a dab of RTV Black silicone sealer where all gaskets and seals meet.

© 2001 Federal-Mogul Corporation
Form No. I-637 (Rev. 6/01)

Printed in U.S.A.



FEL-PRO INSTALLATION TIPS

Fel-Pro products are the result of exhaustive research and strict quality control. However, no sealing product is better than the quality of its installation.

WATER OUTLET, WATER PUMP, FUEL PUMP AND TIMING COVER GASKETS

If a supplementary sealer is desired, apply a thin coat of gasket sealer to both sides of gasket(s).

FLYWHEEL BOLTS

REINSTALL FLYWHEEL to crankshaft. Note: On some engines that use a one-piece rear main bearing seal, a condition may exist where the bolt holes in the crankshaft rear flange have been drilled too deep by the manufacturer. This can result in oil seepage which may be misdiagnosed as coming from the oil pan or rear main bearing seal. To prevent seepage, coat bolt threads with thread locking sealer. Torque securely to OEM specifications.

ROTATING SHAFT SEALS

RUBBER SEAL(S): Install seal with its **largest raised sealing lip toward the engine**. Two-piece rubber seals may be installed using a "shoehorn" installation aid placed underneath seals to protect them from sharp edges.

ROPE SEALS: Install seals into grooves of cap and block by firmly pressing packing into grooves with a "packing tool." Ensure that ends of seals protrude above face of cap and block.

-Continued-

IMPORTANT: Final interference of rope packing seals against crankshaft is critical. To achieve proper interference, it is best to install packings using correct **Packing Tool** for your engine. With "packing tool" in position, cut protruded ends of seals flush with cap and block.

LUBRICATE SEALING LIPS AND CRANKSHAFT with motor oil or grease. If engine will not be started within several days, grease is recommended.

IMPORTANT: Never install any seal without break-in lubricant protection.

REAR MAIN BEARING CAP: Prior to installation, apply anaerobic sealant to mating surfaces of cap or block. Avoid sealant on ends of seals.

OIL PAN GASKET

ATTACH AND ALIGN GASKET(S). Apply a quick-drying adhesive sparingly. Mount gasket and/or seals.

PRIOR TO INSTALLING OIL PAN apply a dab of RTV Black silicone sealer where all gaskets and seals meet.

© 2001 Federal-Mogul Corporation
Form No. I-637 (Rev. 6/01)

Printed in U.S.A.