

## GF5727B

### Assembly of six-way connector

1. Slide large green seal in place.
2. Insert cavity plug into opening "F".
3. Insert terminal & wire assemblies in openings A, B, C, D, E, making sure small green seal on each terminal is completely inside the opening.
4. Fold up large bracket, until it locks, making sure none of the wires are pinched.

### Montage du connecteur à 6 bornes

1. Glisser en place le grand joint vert.
2. Insérer le bouchon de cavité dans l'ouverture « F ».
3. Insérer les cosses et les fils assemblés dans les ouvertures A, B, C, D et E en vérifiant que le petit joint vert de chaque plot est entièrement inséré dans l'ouverture.
4. Replier la grande patte jusqu'à ce qu'elle soit verrouillée, en s'assurant de ne pincer aucun fil.

### Armado del conector de seis cables

1. Deslice la junta verde grande hacia su posición.
2. Introduzca el tapón de la cavidad en la abertura "F".
3. Introduzca los conjuntos de terminal y cable en las aberturas A, A, C, D, E, cerciorándose de que la junta verde pequeña de cada terminal esté completamente dentro de la abertura.
4. Doble el soporte grande hasta que quede trabado, cerciorándose de que ninguno de los cables quede pellizcado.

