
Vehicle Relearn Instruction*

Before beginning installation and vehicle relearn, verify application fitment with your parts provider or online at www.vdo.com/usa or www.redi-sensor.com

SAP # V0511019876VW-A

1. Activate parking brake. Adjust tires to vehicle placard pressure.
2. On end of wiper stalk, hold RESET button until DISPLAY TYPE is displayed. Select SET.
3. Press RESET button.
4. Select TIRE PRESSURE.
5. Press RESET button.
6. Select WHEEL CHANGE (if resetting tire pressure, select STORE PRESSURES).
7. Press RESET button. Allow up to 20 minutes for system to complete relearn process.

*Procedure assumes OE (original equipment) wheels, OE tires, OE TPMS sensors (direct TPMS) or REDI-Sensor multi-application TPMS sensors (direct TPMS), and may vary if otherwise equipped.