

# Vehicle Relearn Instruction\*

Before beginning installation and vehicle relearn, verify application fitment with your parts provider or online at [www.vdo.com/usa](http://www.vdo.com/usa) or [www.redi-sensor.com](http://www.redi-sensor.com)

## SAP # V0511019876VW-G

1. Activate parking brake. Adjust tires to vehicle placard pressure.
2. Insert key and turn ignition ON or RUN (engine off).
3. Hold SET button in glove box until hear chime.
4. If TPMS light was on, it will now turn off indicating successful relearn.

\*Procedure assumes OE (original equipment) wheels, OE tires, OE TPMS sensors (direct TPMS) or REDI-Sensor™ multi-application TPMS sensors (direct TPMS), and may vary if otherwise equipped.