

---

# Vehicle Relearn Instruction\*

Before beginning installation and vehicle relearn, verify application fitment with your parts provider or online at [www.vdo.com/usa](http://www.vdo.com/usa) or [www.redi-sensor.com](http://www.redi-sensor.com)

## SAP # V0511019877CHR-B

1. Activate parking brake. Adjust tires to vehicle placard pressure.
2. Insert key and turn ignition ON (engine off).
3. Press MENU button until RETRAIN TIRE SENSOR-NO displays on screen.
4. Select YES by pressing STEP button.
5. Start relearn process by pressing MENU button. TRAIN LEFT FRONT TIRE will display on screen.
6. For OE sensors place relearn magnet over left-front valve stem or use TPMS scan tool trigger at valve stem until the horn beeps once. Use TPMS scan tool trigger at valve stem for REDI-Sensor.
7. Repeat step 6 for remaining tire valve stems in the following order: right-front, right-rear, left-rear, and spare if equipped. TRAINING COMPLETE will display on screen when cycle is complete.
8. Exit relearn process by pressing and releasing STEP, C/T, RESET, or MENU button.

\*Procedure assumes OE (original equipment) wheels, OE tires, OE TPMS sensors (direct TPMS) or REDI-Sensor multi-application TPMS sensors (direct TPMS), and may vary if otherwise equipped.