
Vehicle Relearn Instruction*

Before beginning installation and vehicle relearn, verify application fitment with your parts provider or online at www.vdo.com/usa or www.redi-sensor.com

SAP # V0511019877GM-A

1. Activate parking brake. Insert key and turn ignition ON (engine off).
2. In 4 seconds or less, quickly turn headlight switch from OFF to parking lamp position 4 times. When learn mode is enabled, the horn will beep twice and the TPMS dash indicator will blink. If headlight switch does not enable learn mode, press the vehicle information button until vehicle learn mode option is displayed.
3. For OE sensors lower the air pressure or use TPMS scan tool trigger at valve stem in the left-front tire until the horn beeps once. Use TPMS scan tool trigger at valve stem for REDI-Sensor.
4. Repeat step 3 for remaining tires in the following order: right-front, right-rear, left-rear.
5. Turn ignition to OFF position and remove key.
6. Adjust tires to vehicle placard pressure.

*Procedure assumes OE (original equipment) wheels, OE tires, OE TPMS sensors (direct TPMS) or REDI-Sensor multi-application TPMS sensors (direct TPMS), and may vary if otherwise equipped.