

Vehicle Relearn Instruction*

Before beginning installation and vehicle relearn, verify application fitment with your parts provider or online at www.vdo.com/usa or www.redi-sensor.com

SAP # V0511019877GM-F

1. Activate parking brake. Adjust tires to vehicle placard pressure.
2. For system to learn new TPMS sensor IDs, vehicle must be operated for several minutes at a speed of 15 mph (25 kph) or more.

*Procedure assumes OE (original equipment) wheels, OE tires, OE TPMS sensors (direct TPMS) or REDI-Sensor™ multi-application TPMS sensors (direct TPMS), and may vary if otherwise equipped.