

**54-inch Curved LED Light Bar
Upper Windshield for 2014-15 GM**

15103

1 - Driver Side Bracket
1 - Passenger Side Bracket
2 - Rubber Spacer Pads
7 - 3/16" Rivets

PRE-INSTALLATION

Professional installation by a certified technician is strongly recommended.

Not responsible for altered products. No claims are made regarding any after-market devices. Any and all claims implied in this document excluded.

NOTES:

Light bar not included in kit. Fits curved LED light bar 53 5/8" long from mount point to mount point.

REQUIRED TOOLS:

3/16" Drill Bit Tape Measure Pop Rivet Gun

INSTALLATION INSTRUCTIONS

STEP 1: Disconnect positive battery lead before installation.

STEP 2: Install gaskets on back side of light brackets.

STEP 3: Open doors and measure 18 1/8" from front of A-pillar to lower edge of bracket.

STEP 4: Mark position of bracket.

STEP 5: Holding bracket in place, drill three holes through sheet metal with 3/16" drill bit. **DO NOT** drill any deeper than 1/2" or you may damage the outside surface.

STEP 6: Secure bracket with included 3/16" rivets.

STEP 7: Repeat procedure on other side of vehicle.

STEP 8: Install LED light bar per instructions included with kit.

STEP 9: Reconnect positive battery lead.

POST-INSTALLATION

MAINTENANCE: Periodically check to ensure that all fasteners are properly tightened.