

# Remanufactured Engines Engine Installation Bulletin

## Oil & Break-in Procedures

Please use a quality conventional, non-synthetic/non-synthetic blend oil in the O.E. specified weight for the duration of the break-in of your remanufactured engine.

The oil should be changed after the first 600 miles of use.

Please allow a total of 5,000 miles for the break-in procedures to be completed.

Do not use synthetic or synthetic blend oils during this break-in period.

