
Vehicle Relearn Instruction*

Before beginning installation and vehicle relearn, verify application fitment with your parts provider or online at www.vdo.com/usa or www.redi-sensor.com

SAP # V0511019876NIS-A

When replacing sensors, a suitably formatted scan tool is required to learn new sensor IDs.

1. Activate parking brake. Adjust tires to vehicle placard pressure.
2. Follow TPMS scan tool prompts for vehicle application. Trigger left-front TPMS sensor at valve stem by using TPMS scan tool trigger. Repeat for remaining sensors in the following order: right-front, right-rear, left-rear.
3. Turn ignition to ON (engine off). Connect OBDII cable to vehicle OBDII port and TPMS scan tool.
4. When OBDII connection is made, scan tool will display that sensor IDs are uploading (or similar). The process may take upwards of 1-minute.

Under normal driving conditions, the system will automatically relearn after a tire rotation or tire replacement (no sensor replacement).

*Procedure assumes OE (original equipment) wheels, OE tires, OE TPMS sensors (direct TPMS) or REDI-Sensor multi-application TPMS sensors (direct TPMS), and may vary if otherwise equipped.